



ANALYTICAL REPORT

Customer: Marc Stammbach
Hitachi Zosen Inova Australia Pty Ltd
Level 17, 40 Mount Street,
North Sydney NSW 2060, Australia

Your Reference: Incinerator ash analyses and waste classification against Western Australia guidelines

SGS Report Number: ENV25214-WA (SE160165)

Date of Receipt of Samples: 12/12/2016

Sample/work Description: Comprehensive analyses for four incinerator ash samples and Landfill waste classification against Western Australia guidelines

This work has been carried out in accordance with your instructions. The results and associated information are contained in the following pages of the report. Should you have any queries regarding this report please contact the undersigned.

Reported by: Angus Ku
Senior Chemist

Date: 23th December 2016

Report authorised by: Paul Pui
Senior Analytical Consultant

Date: 23th December 2016



This document is issued, on the Client's behalf, by the company under its General Conditions of Service available on request and accessible at http://www.sgs.com/terms_and_conditions.htm. The client's attention is drawn to the limitation of liability, indemnification and jurisdiction issues defined therein.

Any other holder of this document is advised that information contained hereon reflects the company's findings at the time of its intervention only and within the limits of client's instructions, if any. The company's sole responsibility is to its client and this document does not exonerate parties to a transaction from exercising all their rights and obligations under the transaction documents.

This test report shall not be reproduced except in full, without written approval of the laboratory.



Summary

Four ash samples were delivered to SGS for waste analyses and classification. Based on the analytical results of the samples (as it) and the toxicity characteristic leaching procedures (TCLP), the classification of the samples were summarised as follows (against WA waste classification guidelines):

Sample	Class	Reason
SE160165-1 Bottom Ash	Class III Putrescible Landfill	TCLP Cd=0.44 mg/L, Pb=0.45 mg/L, Ni=0.34 mg/L
SE160165-2 APC Residue	Class III Putrescible Landfill	Cd=160 mg/kg, TCLP Cd=0.29mg/L, Pb=0.11mg/L
SE160165-3 Bottom Ash/APC Residue = 8/1	Class III Putrescible Landfill	TCLP Cd=0.54mg/L, pb=0.19mg/L
SE160165-4 Boiler + EP ash	Class V Intractable Landfill	TCLP Cd=21mg/L



Sample Description

Four incinerator ash samples from one of the European EfW plants were delivered to SGS on 12/12/2016 for analyses and waste classification. The samples were logged in as follows:

Table 1: Sample ID

Your Reference	SGS sample number
Bottom Ash	SE160165-1
APC Residue	SE160165-2
Bottom Ash/APC Residue = 8/1	SE160165-3
Boiler + EP Ash	SE160165-4

Methods:

A very long list of analytes are mentioned as chemical of interest by various waste classification guidelines. Generally, waste generators have some ideas of the analytes associated with their process, their input and their outputs, and consequently many analytes are not required.

Since the four samples were incinerator ashes from the burned municipal wastes, it was not likely that the wastes would contain a large amount of manufactured industrial chemicals (be they organic or inorganic). It was also logical to assume that most of the organic materials would have been burned during the incineration process. However, as a precautionary principle, an extended list of organic analyses were conducted in this study in case any organic chemicals generated from the possible incomplete combustion should have been overlooked.

Along with organic analyses, a number of inorganic tests were also performed including pH, fluoride, cyanide etc and, most importantly, heavy metals.

Based on the preliminary results of the ash samples, toxicity characteristic leaching procedures (TCLP) further analyses were decided based on the guideline. Final assessment for the waste classification would then be based on both the direct ash analytical results and the TCLP results.



The samples were visually examined and big lumps were grinded to smaller particles in order that homogeneous aliquots taken for analyses could be as representative as possible of the bulk samples. All the methods of the individual analyses were summarised below:

METHOD SUMMARY

A portion of sample is digested with Nitric acid to decompose organic matter and Hydrochloric acid to complete the digestion of metals and then filtered for analysis by ASS or ICP as per USEPA Method 200.8.

A portion of sample is digested with nitric acid to decompose organic matter and hydrochloric acid to complete the digestion of metals. The digest is then analysed by ICP OES with metals results reported on the dried sample basis. Based on USEPA method 200.8 and 6010C.

This method uses an alkaline digestion to solubilise both water-soluble and water-insoluble forms of hexavalent chromium in solids. The solution is then pH adjusted and the hexavalent chromium concentration in solution determined colourimetrically.

Discrete Analyser. A buffered distillate or water sample is treated with chloramine /barbituric acid reagents and the intensity of the colour developed is proportional to the cyanide concentration.

Hydrogen cyanide is liberated from an acidified alkali soil extract by distillation and purging with air. The hydrogen cyanide gas is then collected by passing it through a sodium hydroxide scrubbing solution. The scrubbing solution will then be analysed for cyanide by the appropriate method.

pH in Soil Sludge Sediment and Water: pH is measured electrometrically using a combination electrode and is calibrated against 3 buffers purchased commercially. For soils, sediments and sludges, an extract with water (or 0.01M CaCl₂) is made at a ratio of 1:5 and the pH determined and reported on the extract. Reference APHA 4500-H+.

Fluoride can be measured in soil as water extractable or 'total' by Ion Selective electrode. In this method the solid sample is weighed and then fused with sodium hydroxide at 600°C. The sample is carefully neutralise with hydrochloric acid and the solution of the melt is cooled and made up to volume. The final solution is then compared to synthetic Digestion Matrix standards with analysis by ISE electrode for a total fluoride result after being calculated back to original mass.



Cr6+ is determined colourimetrically by reaction with diphenylcarbazide in acid solution. A red-violet colour of unknown composition is produced.

A buffered distillate or water sample is treated with chloramine /barbituric acid reagents and the intensity of the colour developed is proportional to the cyanide concentration by Aquakem DA .

Mercury by Cold Vapour AAS in Soils: After digestion with nitric acid, hydrogen peroxide and hydrochloric acid, mercury ions are reduced by stannous chloride reagent in acidic solution to elemental mercury. This mercury vapour is purged by nitrogen into a cold cell in an atomic absorption spectrometer or mercury analyser. Quantification is made by comparing absorbances to those of the calibration standards. Reference APHA 3112/3500

Total Recoverable Hydrocarbons: Determination of Hydrocarbons by gas chromatography after a solvent extraction. Detection is by flame ionisation detector (FID) that produces an electronic signal in proportion to the combustible matter passing through it. Total Recoverable Hydrocarbons (TRH) are routinely reported as four alkane groupings based on the carbon chain length of the compounds: C6-C9, C10-C14, C15-C28 and C29-C36 and in recognition of the NEPM 1999 (2013), >C10-C16 (F2), >C16-C34 (F3) and >C34-C40 (F4). F2 is reported directly and also corrected by subtracting Naphthalene (from VOC method AN433) where available.

Additionally, the volatile C6-C9 fraction may be determined by a purge and trap technique and GC/MS because of the potential for volatiles loss. Total Petroleum Hydrocarbons (TPH) follows the same method of analysis after silica gel cleanup of the solvent extract. Aliphatic/Aromatic Speciation follows the same method of analysis after fractionation of the solvent extract over silica with differential polarity of the eluent solvents .

The GC/FID method is not well suited to the analysis of refined high boiling point materials (ie lubricating oils or greases) but is particularly suited for measuring diesel, kerosene and petrol if care to control volatility is taken. This method will detect naturally occurring hydrocarbons, lipids, animal fats, phenols and PAHs if they are present at sufficient levels, dependent on the use of specific cleanup/fractionation techniques. Reference USEPA 3510B, 8015B.



(SVOCs) including OC, OP, PCB, Herbicides, PAH, Phthalates and Speciated Phenols (etc) in soils, sediments and waters are determined by GCMS/ECD technique following appropriate solvent extraction process (Based on USEPA 3500C and 8270D).

SVOC Compounds: Semi-Volatile Organic Compounds (SVOCs) including OC, OP, PCB, Herbicides, PAH, Phthalates and Speciated Phenols in soils, sediments and waters are determined by GCMS/ECD technique following appropriate solvent extraction process (Based on USEPA 3500C and 8270D).

Contaminants of interest in a waste material are leached out of the waste with a selected leaching solution under controlled conditions. The ratio of sample to extraction fluid is 100g to 2 L (1 to 20 by mass). The concentration of each contaminant of interest is determined in the leachate by appropriate methods after separation from the sample by filtering. Base on USEPA 1311.

Extraction Fluid #1: This fluid is made by combining 128.6mL of dilute sodium hydroxide solution and 11.5mL glacial acetic acid with water and diluting to a volume of 2 litres. The pH of this fluid should be 4.93 ± 0.05.

Extraction Fluid #2: This fluid is made by diluting 5.7mL glacial acetic acid with water to a volume of 1 litre. The pH of this fluid should be 2.88 ± 0.05.

Unpreserved water sample is filtered through a 0.45µm membrane filter and acidified with nitric acid similar to APHA3030B.

Determination of Fluoride by ISE: A fluoride ion selective electrode and reference electrode combination, in the presence of a pH/complexation buffer, is used to determine the fluoride concentration. The electrode millivolt response is measured logarithmically against fluoride concentration. Reference APHA F- C.

Mercury by Cold Vapour AAS in Waters: Mercury ions are reduced by stannous chloride reagent in acidic solution to elemental mercury. This mercury vapour is purged by nitrogen into a cold cell in an atomic absorption



spectrometer or mercury analyser. Quantification is made by comparing absorbances to those of the calibration standards. Reference APHA 3112/3500.

Metals by ICP-OES: Samples are preserved with 10% nitric acid for a wide range of metals and some non-metals. This solution is measured by Inductively Coupled Plasma. Solutions are aspirated into an argon plasma at 8000-10000K and emit characteristic energy or light as a result of electron transitions through unique energy levels. The emitted light is focused onto a diffraction grating where it is separated into components .

Photomultipliers or CCDs are used to measure the light intensity at specific wavelengths. This intensity is directly proportional to concentration. Corrections are required to compensate for spectral overlap between elements. Reference APHA 3120 B.



Analytical results

Table 2: Analytical results and Western Australia Waste Classification guideline values

	SE160165.0 01		SE160165.0 02		SE160165.0 03		SE160165.0 04		Class I Inert landfill		Class II Putrescible Landfill		Class III Putrescible Landfill		Class IV Secure Landfill	
	Bottom Ash		APC residue		Bottom ash / APC residue 8/1		Boiler + EP ash		Concent ration Limit	Leacha ble concent ration	Concent ration Limit	Leacha ble concent ration	Concent ration Limit	Leacha ble concent ration	Concent ration Limit	Leacha ble concent ration
Analyte Name	Soil (mg/ kg)	Leac hate conc. (mg/ L)	Soil (mg/ kg)	Leac hate conc. (mg/ L)	Soil (mg/ kg)	Leac hate conc. (mg/ L)	Soil (mg/ kg)	Leac hate conc. (mg/ L)	CL1 (mg/kg)	ASLP1 (mg/L)	CL2 (mg/kg)	ASLP2 (mg/L)	CL3 (mg/kg)	ASLP3 (mg/L)	CL4 (mg/kg)	ASLP4 (mg/L)
TRH																
TRH C16-C35 petroleum hydrocarbons (aromatics)	<110	N/A	<110	N/A	<110	N/A	<110	N/A	450	*N/A	450	N/A	4500	N/A	18000	N/A
TRH C10- >C35 petroleum hydrocarbons (aliphatics)	<210	N/A	<210	N/A	<210	N/A	<210	N/A	28000	N/A	28000	N/A	280000	N/A	N/A	N/A
PAHs																



Naphthalene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
2-methylnaphthalene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
1-methylnaphthalene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Acenaphthylene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Acenaphthene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Fluorene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Phenanthrene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Anthracene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Fluoranthene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Pyrene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Benzo(a)anthracene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Chrysene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Benzo(b&j)fluoranthene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Benzo(k)fluoranthene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Benzo(a)pyrene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	5	0.0001	5	0.0001	50	0.001	200	0.01
Indeno(1,2,3-cd)pyrene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Dibenzo(ah)anthracene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A



Benzo(ghi)perylene	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Total PAH (18)	<0.8	N/A	<0.8	N/A	<0.8	N/A	<0.8	N/A	100	N/A	100	N/A	1000	N/A	4000	N/A
OC/OP																
Hexachlorobenzene (HCB)	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Alpha BHC	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Lindane	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Heptachlor	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Aldrin	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Beta BHC	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Delta BHC	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Heptachlor epoxide	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
o,p'-DDE	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Alpha Endosulfan	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Gamma Chlordane	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Alpha Chlordane	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
trans-Nonachlor	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
p,p'-DDE	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Dieldrin	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Endrin	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
o,p'-DDD	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A



o,p'-DDT	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Beta Endosulfan	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
p,p'-DDD	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
p,p'-DDT	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Endosulfan sulphate	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Endrin Aldehyde	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Methoxychlor	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Endrin Ketone	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Isodrin	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Mirex	<0.1	N/A	<0.1	N/A	<0.1	N/A	<0.1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Dichlorvos	<0.5	N/A	<0.5	N/A	<0.5	N/A	<0.5	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Dimethoate	<0.5	N/A	<0.5	N/A	<0.5	N/A	<0.5	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Diazinon (Dimpylate)	<0.5	N/A	<0.5	N/A	<0.5	N/A	<0.5	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Fenitrothion	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Malathion	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Chlorpyrifos (Chlorpyrifos Ethyl)	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Parathion- ethyl (Parathion)	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Bromophos Ethyl	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Methidathion	<0.5	N/A	<0.5	N/A	<0.5	N/A	<0.5	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Ethion	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A



Azinphos-methyl (Guthion)	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
PCB																
Arochlor 1016	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Arochlor 1221	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Arochlor 1232	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Arochlor 1242	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Arochlor 1248	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Arochlor 1254	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Arochlor 1260	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Arochlor 1262	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Arochlor 1268	<0.2	N/A	<0.2	N/A	<0.2	N/A	<0.2	N/A	50	N/A	50	N/A	50	N/A	50	N/A
Total PCBs (Arochlors)	<1	N/A	<1	N/A	<1	N/A	<1	N/A	50	N/A	50	N/A	50	N/A	50	N/A
pH																
pH	12.1	N/A	11.8	N/A	11.9	N/A	6.5	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Fluoride																
Total Fluoride	490	2.50	200	3.40	390	2.60	3700	17	10000	15	10000	15	100000	150	400000	1500
Cyanide																
Free Cyanide	<0.5	N/A	<0.5	N/A	<0.5	N/A	<0.5	N/A	1250	0.35	1250	0.35	12500	3.5	50000	35
Total Cyanide	<0.5	N/A	<0.5	N/A	<0.5	N/A	<0.5	N/A	2500	0.8	2500	0.8	25000	8	100000	80
Heavy metals																
Aluminium, Al	22000	0.07	12000	0.02	25000	0.04	19000	1.3	50000	N/A	50000	N/A	100000	N/A	200000	N/A



Antimony, Sb	88	0.27	230	2.00	94	0.64	520	0.16	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Arsenic, As	10	0.04	32	0.06	13	0.05	55	0.03	500	0.5	500	0.5	5000	5	20000	50
Barium, Ba	250	0.26	120	2.00	170	0.79	<0.5	0.33	50000	N/A	50000	N/A	100000	N/A	200000	N/A
Beryllium, Be	<0.5	N/A	<0.5	N/A	<0.5	N/A	<0.5	N/A	100	0.1	100	0.1	1000	1	4000	10
Boron, B	190	1.80	62	1.80	110	1.50	190	5.1	50000	N/A	50000	N/A	100000	N/A	200000	N/A
Cadmium, Cd	13	0.44	160	0.29	35	0.54	430	21	100	0.1	100	0.1	1000	1	4000	10
Chromium, Cr	120	N/A	52	N/A	130	N/A	110	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Chromium Hexavalent, Cr6+	0.5	N/A	<0.5	N/A	<0.5	N/A	<0.5	N/A	500	0.5	500	0.5	5000	5	2000	50
Cobalt, Co	20	N/A	10	N/A	13	N/A	20	N/A	50000	N/A	50000	N/A	100000	N/A	200000	N/A
Copper, Cu	1600	1.30	480	0.66	1100	0.31	1600	0.01	50000	N/A	50000	N/A	100000	N/A	200000	N/A
Iron, Fe	25000	N/A	3000	N/A	7000	N/A	9100	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Lead, Pb	1200	0.45	1200	0.11	1000	0.19	3900	3	1500	0.1	1500	0.1	15000	1	60000	10
Lithium, Li	15	0.13	13	0.21	13	0.15	40	1.5	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Manganese, Mn	450	N/A	470	N/A	450	N/A	450	N/A	50000	N/A	50000	N/A	100000	N/A	200000	N/A
Mercury	<0.05	<0.0001	10	0.0003	0.92	0.0012	0.28	<0.0001	75	0.01	75	0.01	750	0.1	3000	1
Molybdenum, Mo	13	0.13	5	0.14	11	0.13	20	0.02	1000	0.5	1000	0.5	10000	5	40000	50
Nickel, Ni	87	0.34	25	0.12	94	0.19	68	0.21	3000	0.2	3000	0.2	30000	2	120000	20
Phosphorus, P	4400	0.47	3200	0.11	3900	0.40	4100	0.19	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Selenium, Se	<3	N/A	<3	N/A	<3	N/A	9	0.06	50	0.5	50	0.5	500	5	2000	50
Silver, Ag	4	<0.005	11	0.01	4	<0.005	33	<0.005	180	1	180	1	1800	10	7200	100
Tin, Sn	100	<0.05	320	<0.05	160	<0.05	1100	<0.05	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Vanadium, V	22	0.04	23	0.08	18	0.05	20	0.02	50000	N/A	50000	N/A	100000	N/A	200000	N/A
Zinc, Zn	5700	110	10000	13.00	5500	45.00	36000	1800	50000	N/A	50000	N/A	100000	N/A	200000	N/A

*N/A = non applicable

Based on the analytical results, the four ash samples should be classified as follows (against the Western Australia guidelines)

Table 3: Classification of the samples (against WA guidelines)

Sample	Class	Reason
SE160165-1 Bottom Ash	Class III Putrescible Landfill	TCLP Cd=0.44 mg/L, Pb=0.45 mg/L, Ni=0.34 mg/L
SE160165-2 APC Residue	Class III Putrescible Landfill	Cd=160 mg/kg, TCLP Cd=0.29mg/L, Pb=0.11mg/L
SE160165-3 Bottom Ash/APC Residue = 8/1	Class III Putrescible Landfill	TCLP Cd=0.54mg/L, pb=0.19mg/L
SE160165-4 Boiler + EP ash	Class V Intractable Landfill	TCLP Cd=21mg/L

Conclusion:

For all the four incinerator ash samples, even though all the organic parameters results were well below the **Class I Inert Landfill** limit, some of the heavy metal concentrations were high enough, rendering the samples being classified as **Class III Putrescible Landfill** and **Class V Intractable Landfill** respectively.